

QUICK CONNECTION GUIDE



USB-C CABLE CONNECTION ⚡ | D

CONNECT THE DISPLAY USING THE SUPPLIED USB-C CABLE TO A THUNDERBOLT (⚡) PORT OR USB-C PORT ON YOUR COMPUTER THAT SUPPORTS DISPLAYPORT ALT MODE (D) DP-ALT).



HDMI CONNECTION HDMI + ⚡ | D

CONNECT THE DISPLAY USING AN HDMI CABLE TO A HDMI PORT ON YOUR COMPUTER

+

USE THE SUPPLIED USB-C CABLE TO CONNECT TO A USB-C PORT ON YOUR COMPUTER.

IF NO USB-C PORT IS AVAILABLE, A USB-A PORT THAT SUPPORTS DATA + POWER MAY BE USED. (USB-A TO USB-C ADAPTER OR CABLE WILL BE REQUIRED)



POWER ONLY USB-C USB-C PD

THIS PORT CAN BE USED TO SUPPLY POWER ONLY. NO VIDEO OR TOUCH SCREEN FUNCTIONALITY IS AVAILABLE THROUGH THIS PORT. A POWER SOURCE THAT SUPPORTS PD (POWER DELIVERY PROTOCOL) IS RECOMMENDED. USE 5V DC MAX IF USING AN EXTERNAL POWER ADAPTER OR BATTERY.